APPLICATION GUIDE

PRIZMACOAT

How to Apply Prizmacoat Killer Cans

STEP 1. - Prepare and prime the surface as you would any normal paint job.

STEP 2. - Apply your choice of base colors. (For the most dramatic “pop” we recommend Stylin Basecoat Jet Black (KC-ASB-13)

STEP 3. - Allow the base to dry as recommended (usually 10-15 minutes. Air dry).

STEP 4. - Apply 2 light “dusting” coats of the Prizmacoat.

STEP 5. - You will now want to shine a bright light on the surface to decide if you have achieved the desired effect. If so you can now go on to the next step, otherwise add more coats as desired being sure to apply in “light” coats. (Applying Prizmacoat too heavily will cause the Flakes to “stack” and ruin the effect).

STEP 6. - Allow the Prizmacoat to dry (usually 5 minutes. Air dry)

STEP 7. - You can now topcoat it with Alsa's SpeedClear (KC-SC1230) for an automotive grade finish.